


Remote operation

Gear motor



MCH (1 part)

AC 50/60 Hz

48 V	47889
100/130 V	47893
200/240 V	47894
250/277 V	47895
380/415 V	47896
440/480 V	47897

DC


24/30 V	47888
48/60 V	47889
100/125 V	47890
200/250 V	47891

Terminal block (1 part)

For fixed circuit breaker	47074
For drawout circuit breaker	47849



Fixed.



Drawout.

Installation manual

47951

Closing and opening release (XF or MX)

Standard coil (1 part)

AC 50/60 Hz

12 V DC	33658
---------	-------

DC

24/30 V DC, 24 V AC	33659
48/60 V DC, 48 V AC	33660
100/130 V AC/DC	33661
200/250 V AC/DC	33662
277 V AC	33663
380/480 V AC	33664

Communicating coil (1 part)

AC 50/60 Hz


12 V DC	33032
---------	-------

DC


24/30 V DC, 24 V AC	33033
48/60 V DC, 48 V AC	33034
100/130 V AC/DC	33035
200/250 V AC/DC	33036
277 V AC	33037
380/480 V AC	33038

Terminal block (1 part)

For fixed circuit breaker	47074
For drawout circuit breaker	47849



Fixed.



Drawout.

Installation manual

47951

Undervoltage release MN

Undervoltage release (1 part)

AC 50/60 Hz


24/30 V DC, 24 V AC	33668
---------------------	-------

DC


48/60 V DC, 48 V AC	33669
100/130 V AC/DC	33670
200/250 V AC/DC	33671
380/480 V AC	33673

Terminal block (1 part)

For fixed circuit breaker	47074
For drawout circuit breaker	47849



Fixed.



Drawout.

Installation manual

47951

MN delay unit

MN delay unit (1 part)

AC 50/60 Hz

48/60 V AC/DC	R (non-adjustable)	Rr (adjustable)
---------------	--------------------	-----------------

DC

100/130 V AC/DC	33684	33681
200/250 V AC/DC	33685	33682
380/480 V AC/DC		33683

Installation manual

47951

